

# COVERALLS™

Diseñado para "Cubrir Todas" las aplicaciones de Asientos para Tracto - Camiones ...



Gran Espacio en sus 6 bolsas

### Diseño Universal

Para respaldo alto o medio con cabecera, con o sin descansabrazos.  
Compatible con: Seats Inc, Bostrom, National, Sears, Knoodler, Wise, etc.

### Fabricado en Tela/Poly de Uso Rudo

Poliéster-Lona grado 900 asegura su durabilidad para largos recorridos

### Ajuste Comodo

Sistema de cinchos de cordones laterales que permite un ajuste perfecto

### Bolsas Multi Funcionales

6 bolsas localizadas en el respaldo y asiento para un almacenaje más organizado

### Resistente a Líquidos y Manchas

Mantiene afuera las gotas de agua previniendo manchas y protege al asiento

seats →



INSTALACION FACIL

## INSTRUCCIONES DE INSTALACION PARA:

## DISPONIBLE EN 4 COMBINACIONES DE COLOR

# COVERALLS™

1. Place the seat cover over the back of seat and pull down. Make sure the front panel is square on the front of the seat.  
\*Seat with armrest(s). (LH armrest(s) to "UP" position. While pulling seat cover down, secure armrest(s) under drawslings and back end apex of top of seat cover's nearest opening (D\*) identified in drawing.



2. Push the center strap through the middle of the seat, enabling it to be pulled through from behind.



3. Pull the seat cover forward and neatly position the front and side panels down the base of the seat.



4. For seats with side plastic moldings it is preferable to position the seat cover between the molding and the seat thereby allowing access to any seat controls.



5. Smooth out the seat cover and pull the front flap under the seat. Ensure the center back strap is straight. The seat cover will need to be aligned to the shape of the seat after a few uses.



6. Make sure all straps are in position and not interfering with the seat mounting tracks or other seat controls. Clip together and pull for tension. Tighten side cord as required.



7. Fasten the velcro backrest strap (D\*). This is best completed when the seat is fully extended.

A\* = Elastic Draw Strap B\* = Center Strap (from Step 2) C\* = Velcro Side (attached back onto material strap) D\* = Velcro Backrest Strap E\* = Armrest Opening



#181704XN1181 - HD  
#182704XN1181 - MD  
Block/Block



#181704XN1182 - HD  
#182704XN1182 - MD  
Block/Blue Two-Tone



#181704XN1183 - HD  
#182704XN1183 - MD  
Block/Mocha Two-Tone



#181704XN1184 - HD  
#182704XN1184 - MD  
Block/Grey Two-Tone