


2. Insert By Aligning Switch Bracket with Receptacle



3. Rotate Clockwise Approx. 45 degrees To Secure



SEATS INCORPORATED ASSUMES NO RESPONSIBILITY FOR DAMAGE OR INJURY CAUSED BY IMPROPER SPACING TO VEHICLE CONTROLS OR INSTALLATION METHOD. THIS IS ONLY A GUIDELINE AND DOES NOT GUARANTEE SATISFACTORY SEAT FUNCTION DUE TO INCOMPLETE OR IMPROPER INSTALLATION. PARTS SUPPLIED BY SEATS INCORPORATED ARE COVERED BY A LIMITED WARRANTY.